



HIGH PERFORMANCE STROLLERS



**Deep
Padded
Reclining
Seat**

City Classic Single

**Amazing 360° Turns
Make For Extreme Maneuverability**

This product complies with ASTM F833-05a

This product complies with BS EN 1888:2003 inc. A1,2,3: 2005

*Read these
instructions carefully
before use and
keep them for
future reference.*

*Your child's safety may be
affected if you do not follow
these instructions.*

Thank You!

We wish you many happy journeys with your new stroller! Your stroller is a great product, and we are proud to manufacture it. If you have any questions or comments, please give us a call at:

1.800.241.1848



H I G H P E R F O R M A N C E S T R O L L E R S

For the sake of your precious cargo, please read these warnings before using your stroller.



- **WARNING:** Prevent serious injury to your child by always using the safety harness.



- **WARNING:** Any load attached to the handle affects the stability of the stroller.



- **WARNING:** It may be dangerous to leave your child unattended.



- **WARNING:** Recommended weight for seat pocket is 2 lbs. (1 kg.) and basket is 10 lbs. (4.5 kg.). Excessive weight may cause a hazardous unstable condition to exist.



- **WARNING:** Not suitable for running or skating.

- Accessories which are not approved by the manufacturer or distributor shall not be used.
- Always use your wrist strap – these strollers can really roll, and the wrist strap gives you control if you should slip or fall down.
- The passenger should remain seated (no standing in the stroller).
- Watch out for cars – never assume that a driver can see you and your child.
- Intended for passengers up to five years of age.
- Total weight load recommended for this stroller is 75 lbs. (34 kg.) (combined passenger and baggage weight.)
- This stroller seats one passenger.
- It may be unsafe to use replacement parts other than those supplied or approved by the manufacturer.
- Never use roller blades while using a Baby Jogger.

Contents



Warnings	1
Frame	3
Front Wheel.....	4
Rear Wheels	5
Safety Harness	6
Brake	7
Reclining Seat	8
Seat	9
Basket.....	10
Accessory Bracket Adapter.....	10
Canopy	11
In Motion	12
Stroller Care.....	13

Frame



WARNING: Ensure all locking devices are engaged before use.



1. Unpack stroller from box and set wheels aside.



2. Unfold adjustable handle by pushing buttons on the sides of stroller handle.



3. Push footplate of stroller away from handle by pushing axle of stroller up and out.



4. The stroller frame will click into place. Turn stroller over to upright position. Snap safety strap to frame before use.



To fold: Unsnap safety strap from frame and pull up on fold strap.

Front Wheel

1 To install front wheel, lay stroller back so the handle is resting on floor. Lock front wheel to prevent the fork from swiveling.

2 Insert the front wheel into the fork tips by aligning the axle flats with the fork tip flats.

3 Tighten by turning the wheel lever clockwise while holding the opposite side.

4 Close the wheel lever making sure that it is flush with the tubing.
Be sure not to over tighten.



Front Wheel Locking Lever
Turn to the left to lock front wheel.

Rear Wheels



- To install, gently slide the rear wheel's axle into the hole in the axle end until you hear it click into place.



- To remove, simply push in the lock button while pulling out the wheel.

Safety Harness



1 Unclip top of shoulder strap from the seat and re-clip on the pair of seat loops closest to child's shoulder height.



2 *To adjust the strap length:* Remove the shoulder pads and move the plastic guide up or down to lengthen or shorten.



3 *To unbuckle the harness:* Press one side of the center button and pull the corresponding side buckle away from the center buckle. Repeat to unbuckle other side.
To buckle: Simply push side buckle into center buckle until it locks in place.



WARNING: Always use the crotch strap in combination with the waist belt.



4 To adjust side straps, press side buckle latch and slide strap to lengthen or shorten.



5 To adjust the center strap, move its plastic guide up or down.

Brake



- Simply push brake pedal down to engage rear parking brake and lift up to release.



WARNING: Engage parking device before loading and unloading passenger.

Reclining Seat



1 *To recline:* Pinch the clamp and slide it down the recline strap to desired recline and push seat down.



2 *To return to the upright position:* Hold the D-ring on the end of the recline strap in one hand and use the other to pinch the clamp and slide it up the strap.



Stroller is packaged with seat support frames and can be easily removed or inserted into the seat backs if additional support is desired.

NOTE: Be sure to remove the frames from the back of the seats before washing.

Seat



WARNING: Always be sure the safety strap is securely snapped onto the frame before using stroller!



1 Snap seat to frame.



2 Wrap bottom straps around frame, thread strap through D-ring and secure.



3 Snap seat strap around rear frame.



4 Thread folding strap through opening in seat.



5 Attach folding strap to folding trigger and secure the triangle shaped fastener.



6 Snap safety strap to frame.

Basket



- 1** Velcro front basket straps around frame tube.
Front of seat will need to be turned up to access frame tube.



- 2** Wrap rear basket straps around upright and snap together.

NOTE: *The rear of basket has the mesh material and the front does not.*

Accessory Bracket Adapter

(Classic, Elite and Mini Series Only)



Accessory Bracket Adapter Allows
for Easy Use of Accessories

Canopy



1 To attach bracket to frame: Unsnap seat from frame to reveal mounting location. Use a phillips head screwdriver to attach bracket screws to frame.



2 To attach canopy to bracket: Insert canopy frame into bracket and attach screws using a phillips head screwdriver.



3 Velcro canopy strap around frame to itself.

In Motion

Steering

- Steering your stroller is simple: It is balanced to turn with just a light touch on the handlebar without having to lift the front wheel.

Wrist Strap

- Make sure wrist strap is attached to bottom crossbar and is secured properly around your wrist whenever a child is in the stroller. The stroller is lightweight and ready to roll – with or without you – and the safety wrist strap helps you gain control over your stroller.

In the Dark

- Since we are concerned about the safety of you and your child, we recommend that you not use your stroller at night. However, if you choose to, please attach reflective strips to the wheel spokes and the seat. Bicycle lights can also be mounted on the handle crossbar. These accessories can be found at most bike stores.



Stroller Care

Washing

- You can machine wash your stroller's seat in cold water with a mild detergent. To minimize shrinkage, simply reattach the seat to the frame to dry. (Please do not put the seat in the dryer!)
- Be sure to remove the frame from the back of the seat before washing.
- The stroller frame can be cleaned using a soft, dry cloth, and an occasional spray of household wax will maintain its healthy glow.



Wheel Care

- Moisture – especially from the beach – can rust the wheel. Spraying regularly with a silicone lubricant will keep your wheels looking healthy.

Storing

- Sunshine can fade seat fabric and dry out tires, so storing your stroller indoors will prolong its good looks. However, if you do store it outside, using a tarp will help protect against weather wear.

www.babyjogger.com



H I G H P E R F O R M A N C E S T R O L L E R S

Baby Jogger is a Division of Dynamic Brands

8575 Magellan Parkway, Suite 1000 • Richmond, VA 23227

T: 800.241.1848 • F: 804.262.6277

www.babyjogger.com